

CANdb++ Report "Messages"

Name	ID	DLC	ID-Format	Transmitter	TX-Method	Cycletime [ms]	Comment
BB_InputStatus	0x202	2	CAN Standard	BB_EV_Node	Cyclic	100	
CONF_SOCM_Config1	0x750	8	CAN Standard	TESTER_EV_Node	Cyclic	100	This frame is used to configure the S
DD_BBReadReqResp_RT	0x208	8	CAN Standard	DD_EV_Node	Cyclic	100	This CAN frame is used to request i
DD_BBWriteRequest	0x210	3	CAN Standard	DD_EV_Node	Cyclic	100	This CAN frame is used to change da
SOCM_ActualAmps	0x701	8	CAN Standard	SOCM_EV_Node	Cyclic	100	
SOCM_ActualVolts	0x703	8	CAN Standard	SOCM_EV_Node	Cyclic	100	
SOCM_AhValues	0x705	8	CAN Standard	SOCM_EV_Node	Cyclic	100	
SOCM_AnalogValues	0x704	8	CAN Standard	SOCM_EV_Node	Cyclic	100	
SOCM_InstAmps	0x700	8	CAN Standard	SOCM_EV_Node	Cyclic	100	
SOCM_InstVolts	0x702	8	CAN Standard	SOCM_EV_Node	Cyclic	100	
SOCM_Status	0x709	8	CAN Standard	SOCM_EV_Node	Cyclic	100	
SOCM_VehicleSpeed	0x708	8	CAN Standard	SOCM_EV_Node	Cyclic	100	
SOCM_WhRange	0x707	8	CAN Standard	SOCM_EV_Node	Cyclic	100	
SOCM_WhValues	0x706	8	CAN Standard	SOCM_EV_Node	Cyclic	100	